


## 1 PC. HEATER BAND WIRING


## **PARALLEL WIRING:**

HEATER BANDS ARE NORMALLY WIRED IN PARALLEL BY ZONES



**SERIES WIRING:** ILLUSTRATION SHOWS 240V BANDS WIRED TO

ACCEPT 480V. BANDS MUST BE OF EQUAL WATTAGE AND WIRED BY PAIRS IN SERIES





CAUTION: follow equipment manufacturers instructions when working on any electrical items, (wiring, controls, heater bands, cartridge heaters, etc.,.)

## HOW TO WIRE DUAL VOLTAGE BANDS

120/240V

1) CONNECT WHITE TO COMMON 2) JOIN TWO REDS TO OTHER LINE





1) TAPE WHITE WIRE & DO NOT USE

2) CONNECT ONE RED TO EACH

SIDE OF LINE

120 Volts Don't Use 240 Volts

240/480V

